

SC1240 - FITTING INSTRUCTIONS

INSECT SCREEN CURTAINS - VW T5/T6 SLIDING DOOR



1
Unpack your insect screen. Make sure screen is the correct way up as it is tailored to the door frame.



2
Allow the magnets to snap onto the door frame.



3
Fit around the whole door frame.



4
Close all the gaps.



5
Access to the vehicle is by the two way zip.



6
Clip the screen to the vehicle to allow easy access.



SC1240 - FITTING INSTRUCTIONS

INSECT SCREEN CURTAINS - VW T5/T6 SLIDING DOOR



Removal is the reverse of fitting.



Pack in the bag for easy storage.



Self adhesive metal tabs are supplied should the vehicle have a none metal surface.