



Remove headrests from your seats



Slide driver's cover over the driver's seat



Push bottom of the cover through the seat join



Attach the velcro at the back of the driver's seat



Push the material underneath the headrest guide inserts



Push the driver's seat base cover through the seat join





Tuck the material into sides of the seat moulding



Attach hooks to the elastic bands on the bottom of the cover



Attach the hooks to the underside of the seat securely



Remove any armrest caps on the armrest



Slide the armrest covers fully over the armrests



Tuck the material underneath the hinge cap, and reattach cap






Attach and velcro the headrest cover to the headrest



Lift seat base and slide on base covers



On the underside, fold the tab underneath upholstery fixing



Secure all tabs underneath the edge



Slide the back covers over the back of the passenger seats



Tuck the material underneath the seatbelt housing





Tuck the velcro flap behind the underneath of the seats



Attach the velcro securely at the back of the seats



Attach the plastic hook behind the pull down tray panel



Slide the tray cover on, pulling through the fabric loop



Pull through velcro and attach securely at the base of the tray



Assemble and enjoy your seat covers